

B) Setting of the transmission code with humidity value

- Press (long press > 0.5 s) the PROG button once and then press it briefly once. The green illumination of the LED in the cover signals that the transmission is switched ON while the red illuminating of the one signals that the transmission is switched OFF.
- Press (long press > 0.5 s) the PROG button for changing the setting.
- Press (brief press) the INI button to save the settings. It will be indicated by a simultaneous slow green blink of LED 1 and LED 2.

C Setting of the transmission code with CO₂ value

- Press (long press > 0.5 s) the PROG button once and then press it briefly twice. The green illumination of the LED in the cover signals that the transmission is switched ON while the red illuminating of the one signals that the transmission is switched OFF.
- Press (long press > 0.5 s) the PROG button for changing the setting.
- Press (brief press) the INI button to save settings. It will be indicated by a simultaneous slow green blink of LED 1 and LED 2.

D) Setting of the transmission code for the control of the CO₂ concentration

- Press (long press > 0.5 s) the PROG button once and then press it briefly three times. The green illumination of the LED in the cover signals that the transmission is switched ON while the red illuminating of the same one signals that the transmission is switched OFF.
- Press (long press > 0.5 s) the PROG button for changing the setting
- Press (brief press) the INI button for save settings. It will be indicated by simultaneous slow green blink of LED 1 and LED 2.

E) Setting of the transmission repetition of the code for the control of the CO₂ concentration

- Press (long press > 0.5 s) the PROG button once and then press it briefly four times. The green illumination of the LED in the cover signals that the transmission repetition is switched ON while the red illuminating of the same one signals that the transmission repetition is switched OFF
- Press (long press > 0.5 s) the PROG button for changing the setting
- Press (brief press) the INI button to save settings. It will be indicated by simultaneous slow green blink of LED 1 and LED 2.

F) Setting of the acoustic signal

- Press (long press > 0.5 s) the PROG button once and then press it briefly five times. The green illumination of the LED in the cover signals that acoustic signal is switched ON while the red illuminating of the same one signals that the acoustic signal is switched OFF
- Press (long press > 0.5 s) the PROG button for changing the setting
- Press (brief press) the INI button to save settings. It will be indicated by simultaneous slow green blink of LED 1 and LED 2.

G) Setting of the automatic calibration

- Press (long press > 0.5 s) the PROG button once and then press it briefly six times. The green illumination of the LED in the cover signals that the automatic calibration is switched ON while the red illuminating of the same one signals that the automatic calibration is switched OFF.
- Press (long press > 0.5 s) the PROG button for changing the setting
- Press (brief press) the INI button to save settings. It will be indicated by simultaneous slow green blink of LED 1 and LED 2.

Note:

If the transmitting of the code for the control of the CO₂ concentration is switched off, the choice of the transmission repetition setting is omitted. If the controlling of the CO₂ concentration is completely switched off (the rotary switch position is 0), it is omitted moreover the choice of the code for control of the CO₂ concentration and the choice of the acoustic signal.

If there is a need to leave the settings menu without saving changes, long press the INI button. Return to the operating mode will be indicated by alternate quick green flashing of LED 1 and LED 2.

H) Setting of the reference value and the hysteresis for control of the CO₂ concentration

- Set the required value of CO₂ and hysteresis (ppm) on the rotary switch by chart 1.

Transmitting of the initialization code

I) Transmitting of the initialization code with temperature value

- Press (brief press) the PROG button once. It will be indicated by LED 1 and LED 2 illuminated in green.
- Press (brief press) the INI button for transmitting the initialization code. It will be indicated by a slow green blink of both LEDs.

J) Transmitting of the initialization code with humidity value

- Press (brief press) the PROG button twice. It will be indicated by LED 1 illuminated in green and LED 2 illuminated in red.
- Press (brief press) the INI button for transmitting the initialization code. It will be indicated by a slow green blink of both LEDs.

K) Transmitting of the initialization code with CO₂ value

- Press (brief press) the PROG button three times. It will be indicated by the LED 1 illuminated in green and LED 2 flashing red and green.
- Press (brief press) the INI button for transmitting the initialization code. It will be indicated by slow green blink of both LEDs.

L) Transmitting of the initialization code ON+OFF for the control of the CO₂ concentration

- Press (brief press) the PROG button four times. It will be indicated by the LED 1 illuminated in red and the LED 2 flashing red and green.
- Press (brief press) the INI button for transmitting the initialization code. It will be indicated by slow green blink of both LEDs.

M) Transmitting of the initialization code ON for the control of the CO₂ concentration

- Press (brief press) the PROG button five times. It will be indicated by LED 1 illuminated in red and LED 2 illuminated in green.
- Press (brief press) the INI button for transmitting the initialization code. It will be indicated by a slow green blinking of both LEDs.

N) Transmitting of the initialization code OFF for the control of the CO₂ concentration

- Press (brief press) the PROG button six times. It will be indicated by LED 1 and LED 2 illuminated in red.
- Press (brief press) the INI button for transmitting the initialization code. It will be indicated by slow green blink of both LEDs.

Note:

During the selection of the initialization code the LED in the cover is switched off.

O) Start the manual calibration of sensor CO₂

- Press (brief press) the PROG button seven times. It will be indicated by the LED in the cover flashing red and green and LED 1 and LED 2 are off.
- Press (brief press) the INI button for starting the calibration of the sensor CO₂. It will be indicated by a red flashing of the LED in the cover during the calibration.

Note:

The sensor must be in a well-ventilated area during the calibration.

Running the test mode

- Press the PROG button for more than 10 s.
- LED 1 starts flashing quickly green and the sensor switches into the test mode, in which the measured temperature value, humidity value, CO₂ value and alternately code ON/OFF is transmitted approximately every 10 s.
- Press the button again to end the test mode (it will also end automatically after 10 minutes).

Note:

In the rotary switch position 1, 2, 4 and 8 is the transmitting value of the temperature fixed at 1, 2, 4 and 8 °C.

Hereby, ENIKA.CZ s.r.o. declares that the radio equipment type P8 T CO2 Time/Element is in compliance with Directive 2014/53/EU. The full text of the EU Declaration of conformity is available at the following internet address: www.enika.cz.

Technická data / Technical data	P8 T CO2 Time/Element
Přesnost měření teploty / Temperature measurement accuracy:	±0,5 K
Rozlišení / Resolution:	0,0625 K
Přesnost měření vlhkosti / Humidity measurement accuracy:	±4,5 % v rozsahu / in range 20 až / to 80 %RH ±7,5 % v rozsahu / in range 0 až / to 20 %RH 80 až / to 100 %RH
Rozlišení / Resolution:	0,025 %
Přesnost měření koncentrace CO ₂ / Concentration of CO ₂ measurement accuracy:	±50 ppm + ±3% z hodnoty* / of reading* v rozsahu / in the range 400 až / to 3000 ppm
Rozlišení / Resolution:	1 ppm
Interval měření / Measurement interval:	asi / approximately 1 min
Interval vysílání / Transmission interval:	max. 10 min
Doba ustálení / Setting time:	2 hodiny / hours
Napájení / Power supply:	230 V ±10 % 50 Hz
Maximální spínaný výkon / Output power:	3700 W 250 V~ AC1 750 VA 250 V~ cosφ>0,8
Připojovací svorky / Connecting terminals:	2,5 mm ²
Stupeň krytí / Degree of protection:	IP 20 podle / according to ČSN EN 60529
Spínací prvek / Switching element:	relé / relay
Provozní teplota / Operating temperature:	0 až / to + 45 °C
Provozní kmitočet / Frequency:	868,3 MHz
Vf výkon / RF power:	10 dBm
Dosah / Range:	150 m ve volném prostoru / in open space
Počet kódů / Number of codes:	2 ²⁴
Hmotnost / Weight:	120 g

* Přesnost je dosažena po provedené kalibraci nebo po proběhnutí nejméně 3 automatických kalibračních cyklů. První cyklus po zapnutí jednotky trvá 3 dny, každý další cyklus trvá 7 dní. Během každého cyklu musí být prostor vyvětrán tak, aby koncentrace CO₂ v prostoru dosáhla hodnoty cca 400 ppm, což odpovídá koncentraci CO₂ v otevřeném prostoru. / * The accuracy is achieved after calibration or after at least 3 automatic calibration cycles. First cycle, after switch on the unit, lasts 3 days, every next cycle lasts 7 days. The area must be ventilate during every cycle and concentration of CO₂ for this are must be about value 400 ppm. That's value of concentration CO₂ in open area.

Na zařízení není dovoleno provádět dodatečné technické úpravy! / It is forbidden to do any technical modifications on the device!

Zařízení lze provozovat na základě aktuálního VO-R/10/. (viz www.ctu.cz) a za podmínek v něm uvedených.



EU Prohlášení o shodě

Výrobce: ENIKA.CZ s. r. o.
190 00 PRAHA 9, Pod Harfou 933/86
IČO: 28218167

tímto prohlašuje, že výrobek

typové označení: P8 T CO2 Time/Element

specifikace: ---
druh výrobku: Snímač kvality vzduchu
frekvence: 868,3 MHz
vf výkon: 10 dBm

- je ve shodě se základními požadavky evropských direktiv:
2014/53/EU (RED) (dodávání radiových zařízení na trh)
2011/65/EU (RoHS) (omez. používání některých škodlivých látek)

- splňuje požadavky těchto norem a předpisů:

ČSN ETSI EN 300 220-1 V2.4.1:13
ČSN ETSI EN 301 489-1 V1.9.2:12
ČSN EN 60730-2-13 ed.2:08
ČSN EN 50581:2013

Toto prohlášení je vydáno na výhradní odpovědnost výrobce.

V Nové Pace dne 17. 04. 2018

ing. Vladimír Militký,
řízení systému jakosti