

PORTAFUSIBILI DA CIRCUITO STAMPATO

PCB fuseholders | Porte-fusibles pour circuit imprimé

C1018 - CE5518

Per fusibili 5x20	For 5x20 fuses	Pour fusibles 5x20
C1018 Portafusibile 10 A 300 V Contatti Ottone stagnato Base Noryl 66- UL-94V0 nero CE5518 Coperchio	C1018 Fuseholder 10 A 300 V Contatti Tinned brass Base 66-UL94V0 black noryl CE5518 Cover	C1018 Porte-fusible 10 A 300 V Contacts Laiton étamé Base Noryl 66- UL-94V0 noir CE5518 Capot

Categoria PC1

500 pcs
 500 pcs
 pronta in stock
 en stock

C1020 - CE5526

Per fusibili 5x20	For 5x20 fuses	Pour fusibles 5x20
C1020 Portafusibile 6 A 250 V Contatti Ottone stagnato Base Noryl UL66-V0 nero CE5526 Coperchio estraattore Materiale coperchio Noryl autoestinguente	C1020 Fuseholder 6 A 250 V Contatti Tinned brass Base UL66-V0 black noryl CE5526 Extractor cover Cover material Noryl self-extinguishing	C1020 Porte-fusible 6 A 250 V Contacts Laiton étamé Base Noryl UL66-V0 noir CE5526 Capot extracteur Materiau capot Noryl auto-extinguible

Categoria PC1

500 pcs
 500 pcs
 pronta in stock
 en stock

C1024 - CE5527

Per fusibili 5x20	For 5x20 fuses	Pour fusibles 5x20
C1024 Portafusibile 5 A 250 V Contatti Ottone stagnato Base	C1024 Fuseholder 5 A 250 V Contatti Tinned brass Base	C1024 Porte-fusible 5 A 250 V Contacts Laiton étamé Base

Categoria PC1